



Installation Instructions Play Centre (3 Sided)

DO NOT ATTEMPT TO INSTALL THIS PRODUCT IF YOU DO NOT FEEL COMPETENT TO DO SO

We can arrange installation for you at additional charge. Call us on (02) 9984 0769.

Congratulations! Your Child Friendly Solutions Play Unit is going to provide you with a fantastic competitive edge and give your customers (big and little) something to smile about. Enjoy!

What You Will Need

- Philips Head Screwdriver
- Contents of box including:
 - 3 x Play/Flat Panels
 - 6 x Black Connecting Brackets
 - 12 x Screws (to lock brackets – 2 per bracket)
 - 6 x Feet
 - 6 x Weights
 - 12 x Screws and Washers (to attach weights)



Fig 1 - Connecting Brackets

Step 1 - Unpack contents of boxes and find a suitable position for the Play Centre in your store or home. You will need just under 1 square metre of space. If you are unsure of where to place it, feel free to call us for advice.

Step 2 – Push the feet into the holes in the bottom of each Play Panel, ensuring they are pushed all the way in. There are two feet per panel. Then attach 2 weights to each panel using the supplied screws and washers and your Philips head Screwdriver. The weights are placed over the 2 sets of 2 plastic bosses at the base of each panel. IT IS IMPORTANT THAT THESE WEIGHTS ARE FITTED TO STOP THE UNIT OVERBALANCING WHEN A CHILD PULLS ON IT.



Figure 2

Step 3 – Place two of the panels at sixty degrees to each other and insert the black connecting brackets into the holes provided (one at the top, one at the bottom) with the prongs facing down. See Figure 2. It is important to ensure that all prongs are in the hole, not hanging outside the hole. Insert 2 screws into each bracket and using a screwdriver or drill, screw them into place. Insert the remaining brackets and screws following the order shown in Figure 3.

Step 4 – Place third panel to complete the triangle and insert brackets to hold unit together. To place the final bottom bracket (5), bring the last two sides of the panels together at the bottom, but flex them open above the hole wide enough to get your arm through and place the bracket and partially screw in the screws. Then reach over the top of the play center to drill the bottom screws (in bracket 5) into place. Finally, place the last bracket (6) and screw into place.




Figure 3 - Order in which brackets should be inserted

Guarantee

Child Friendly Solutions' products are guaranteed for a period of 12 months from date of purchase, against defects in workmanship and materials. Kindly retain your purchase receipt as this receipt will need to be presented if replacement is required.

Child Friendly Solutions will replace all defective products, but where a product includes a number of accessories, only the defective accessory, or an equivalent accessory, will be replaced.

If replacement is required, return the product and the purchase receipt to your sales representative or contact head office.

The guarantee naturally does not cover misuse, negligent handling or normal wear and tear.

Terms and Conditions of Supply

1. Trading terms are payment in advance of supply. Where a client has been provided with credit, payment is due within 7 days of receipt of goods.
2. Child Friendly Solutions ("CFS") reserves the right to cancel orders or place orders on hold if the customer does not pay its account within the trading terms herein.
3. Prices are subject to change without notice and are exclusive of GST which will be added.
4. Conditions of sale/return: Returns are not accepted unless goods are returned to CFS unopened in good condition with freight prepaid within 7 days.
5. Competitive freight fees apply to all orders.
6. Risk in the goods shall pass to the customer at the time of delivery by CFS to the customer.
7. Notwithstanding the provisions of item 6, title to the goods shall remain the absolute property of CFS until such time as all moneys owed by the customer to CFS are paid in full.
8. The Director(s) of the customer confirms that the person/s accepting these terms on behalf of the customer has the full authority to do so.
9. The Director(s) of the customer have in consideration of CFS granting to the customer credit at the request of such Director(s) agree to be jointly and severally liable as guarantors to CFS for all of CFS's costs and expenses which the customer fails to pay to CFS.
10. Should goods be refused by the customer at time of delivery without written notification or cancellation having been received by CFS prior to dispatch, the customer shall be liable for the full delivery charge and the return of the goods to CFS's warehouse.
11. Warranty: except as otherwise provided by State or Federal law, CFS gives no warranty in connection with the use of its goods and shall not be liable for any damages, losses, costs, expenses, liabilities or consequential damages whether direct or indirect, and whether or not resulting from or contributed to by the default or negligence of CFS, its agents and employees resulting from the use or failure of the product sold.
12. Governing Law: These terms shall be governed by the laws of the state of New South Wales.